# **BERMAD** Waterworks

### Accessories

## Valve Position Indicator Assembly

The Position Indicator provides a visual indication of valve position and regulation behavior.




## Flow Stem / Mechanical Closure

The Flow Stem enables limiting the opening stroke of a control valve or for safety-ensured mechanical closure.

#### **Typical Applications**

- Surge Anticipating Valves Models 735-M and 735-55-M (For limiting the relief flow)
- Burst Control Valve Model 790-M (For burst flow setting)





The information herein is subject to change without notice. BERMAD shall not be held liable for any errors. All rights reserved. © Copyright by BERMAD. PC7WE0A 09