BERMAD Irrigation



400 Series

Reservoirs

Level Control Valve

with Bi-Level Vertical Float

IR-450-66-Z

The BERMAD Model IR-450-66-Z Level Control Valve with Bi-Level Vertical Float is a hydraulically operated, diaphragm actuated control valve. The valve is hydraulically controlled to fully open at preset reservoir low level and to shut at preset high level.




Features and Benefits

- Line Pressure Driven, Hydraulically Controlled
- Bi-Level Hydraulic Vertical Float
 - On/Off service
 - Low cavitation damage
 - Suitable for low quality water
 - Easy level setting
- Advanced Globe Hydro-Efficient Design
 - Unobstructed flow path
 - Single moving part
 - High flow capacity
- Fully Supported & Balanced Diaphragm
 - Requires low opening and actuation pressure
 - Progressively restrains valve closing
 - Prevents diaphragm distortion
- External Installation
 - Easy access to valve and float
 - Less wear and tear
 - Simple in-line inspection and service

Typical Applications

- Full Range of Low Level Reservoirs
- Unavailable Power Supply Locations
- Low Supply Pressure Systems
- Low Noise Generation Requirements
- Energy Cost-Critical Systems
- Systems with Poor Water Quality



- [1] BERMAD Model IR-450-66-Z opens at reservoir preset low level and shuts at reservoir preset high level.
- [2] Bermad Bi-Level Vertical Float Model "66" in stilling tank
- [3] Check Valve



BERMAD Irrigation

IR-450-66-Z

For full technical details, refer to Engineering Section.


400 Series

Reservoirs

Technical Specifications

Dimensions and Weights

| Size | DN | 80 | 100 | 150 | 200 | 250 | 300 | 350 | 400 |
|--------|------|------|------|-------|-------|-------|-------|-------|-------|
| | Inch | 3 | 4 | 6 | 8 | 10 | 12 | 14 | 16 |
| L | mm | 250 | 320 | 415 | 500 | 605 | 725 | 742 | 742 |
| | inch | 9.8 | 12.6 | 16.3 | 19.8 | 23.8 | 28.5 | 29.2 | 29.2 |
| Н | mm | 210 | 242 | 345 | 430 | 460 | 635 | 655 | 965 |
| | inch | 8.3 | 9.5 | 13.6 | 16.9 | 18.1 | 25 | 25.8 | 38 |
| С | mm | 125 | 145 | 207 | 258 | 276 | 381 | 393 | 579 |
| | inch | 5 | 5.7 | 8.2 | 10.2 | 10.9 | 15 | 15.5 | 22.8 |
| R | mm | 100 | 112 | 140 | 170 | 202 | 242 | 260 | 300 |
| | inch | 3.9 | 4.4 | 5.5 | 6.7 | 8 | 9.5 | 10.2 | 11.8 |
| A; B | mm | 300 | 312 | 353 | 383 | 403 | 490 | 494 | 500 |
| | inch | 11.8 | 12.3 | 13.9 | 15.1 | 15.9 | 19.3 | 19.4 | 19.7 |
| Weight | Kg | 19 | 28 | 68 | 125 | 140 | 290 | 358 | 377 |
| | lb. | 41.9 | 61.7 | 149.9 | 275.6 | 308.6 | 639.3 | 789.2 | 831.1 |



Technical Data

Patterns and Sizes: Globe: 3-16"; DN80-400 Angle: 3-4"; DN80-100 **End Connections:**

| Cimo | | 3" | 4" | 6" | 8-16" |
|----------|-------|------|-------|-------|-----------|
| Size | | DN80 | DN100 | DN150 | DN200-400 |
| Threaded | Globe | - | | | |
| Threaded | Angle | • | | | |
| Florand | Globe | - | • | • | • |
| Flanged | Angle | - | - | | |
| 0 | Globe | - | • | • | |
| Grooved | Angle | | - | | |

Pressure Rating: 16 bar; 232 psi

Operating Pressure Range: 0.5-16 bar; 7-232 psi For lower pressure requirements, consult factory

Materials:

Body and Cover:

Polyester Coated Cast or (10"; DN250 and larger) Ductile Iron

Spring: Stainless Steel


Diaphragm: Nylon fabric Reinforced NR with rugged insert

Bolts, Studs and Nuts: Zinc-Cobalt plated Steel


Control Accessories: Brass

Tubing and Fittings: Reinforced Plastic and Brass

Flow Chart



Operation



Size range: 11/2-8"

Size range: 8-16"

The Float [1] slides along the Rod [2] pulling the Low Level Stopper [3] or pushing the High Level Stopper [4] according to level drop or rise, thereby switching the Float Pilot (FP) [5] position. Upon level rise beyond sliding range, the FP switches open directing line pressure into the Control Chamber [6], and shutting the Valve. Level drop causes the FP switch to close, venting the control chamber and opening the Valve. As long as the float slides between stoppers [3] and [4], the Valve remains in its last position. For 8"; DN200 valves and larger, a 3-Way Hydraulic Relay Valve [7] quickens Valve response. The Manual Selector [8] enables local manual closing.

How to Order

Please specify the requested valve in the following sequence: (for more options, refer to Ordering Guide.)

